DEX Scan & Pair



User Guide for Android ™

Copyright

© 2017 ZIH Corp. and/or its affiliates. All rights reserved. ZEBRA and the stylized Zebra head are trademarks of ZIH Corp., registered in many jurisdictions worldwide. All other trademarks are the property of their respective owners.

COPYRIGHTS & TRADEMARKS: For complete copyright and trademark information, go to www.zebra.com/ copyright.

WARRANTY: For complete warranty information, go to www.zebra.com/warranty.

END USER LICENSE AGREEMENT: For complete EULA information, go to www.zebra.com/eula.

Terms of Use

Proprietary Statement

This manual contains proprietary information of Zebra Technologies Corporation and its subsidiaries ("Zebra Technologies"). It is intended solely for the information and use of parties operating and maintaining the equipment described herein. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the express, written permission of Zebra Technologies.

Product Improvements

Continuous improvement of products is a policy of Zebra Technologies. All specifications and designs are subject to change without notice.

Liability Disclaimer

Zebra Technologies takes steps to ensure that its published Engineering specifications and manuals are correct; however, errors do occur. Zebra Technologies reserves the right to correct any such errors and disclaims liability resulting therefrom.

Limitation of Liability

In no event shall Zebra Technologies or anyone else involved in the creation, production, or delivery of the accompanying product (including hardware and software) be liable for any damages whatsoever (including, without limitation, consequential damages including loss of business profits, business interruption, or loss of business information) arising out of the use of, the results of use of, or inability to use such product, even if Zebra Technologies has been advised of the possibility of such damages. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Revision History

Changes to the original guide are listed below:

Change	Date	Description
-01 Rev A	11/2017	Initial release.

Table of Contents

Copyright Terms of Use Revision History	2 2 2
Table of Contents	3
About This Guide Introduction Direct EXchange	6 6
Installation Introduction Installing DEX Scan & Pair	7 7
Configuration Introduction Pairing to the DX30 Bluetooth KeyFob	9 9

Table of Contents

Table of Contents

About This Guide

Introduction

Direct EXchange

Direct EXchange (DEX) is a digital communication protocol that extends the UCS (Uniform Communication Standard) that enables direct store delivery drivers to transmit digital invoices to the retailer's receiving clerk at the loading dock.

Created by the Uniform Code Council (UCC), DEX has been adopted by most national grocery chains. This standardized system reduces time, costs and inaccuracies inherent in paper invoices. Originally designed in the early 1980's, the DEX protocols have been revised several times over the years. The most current version is 5030 version, released in 2006. Unfortunately, adoption of protocol upgrades has been un-even in the marketplace, requiring DEX software to be adaptable to the specific requirements of each retailer served.

Installation

Introduction

This chapter describes how to install the DEX Scan & Pair application on an Android mobile computer when used with a line of business application.

Installing DEX Scan & Pair

To install the DEX Scan & Pair application:

- 1. Download the DEX Scan & Pair application from the Zebra Support Central web site, www.zebra.com/support.
- 2. Uncompress the file into a folder on the host computer.
- 3. Ensure that the mobile computer is set to allow installation of applications from external source. See system administrator for more information.
- 4. Connect a USB cable to the device and host computer.
- 5. On the mobile computer, open the notification panel and touch **USB for charging**. In the dialog box, select **File transfer**.
- 6. On the host computer, open a file explorer application and locate the Scan & Pair file.
- 7. In another file explorer window, open the mobile device directory tree.
- 8. Open Internal Storage > Download folder.
- 9. Copy the DX300KSNPEN0103.apk file into the Download folder.
- 10. Disconnect the USB cable from the device.
- 11. On the mobile computer, open the All Apps screen.
- 12. Touch File Browser.
- 13. Touch Internal folder.
- 14. Touch Download folder.



		*	† 1 🗎	11:44 AM
File Brov	wser			:
/internal/Do	wnload			
	নন্দ্র	t t		4
DX300KSNPE O	N			

- **15.** Touch the **DX300KSNPEN0103.apk** file to begin the installation process.
- 16. Touch Install.
- **17.** When the installation is complete, a verification message appears.
- **18.** Touch **Open** to launch the application or **Done** to close the installation window.

Configuration

Introduction

This chapter provides instructions on connecting a mobile computer to the DEX30 Bluetooth KeyFob.

Pairing to the DX30 Bluetooth KeyFob

To pair:

1. On the Home screen open All Apps screen.





2. Touch DEX Scan & Pair.

The Welcome screen appears.



IMPORTANT: If Bluetooth is not enabled, a dialog appears requesting to turn on Bluetooth. Touch **Allow**.

Figure 3 Welcome Screen

	4:45 PM
Welcome to DEX Scan &	Pair
Start	>

3. Touch Start.



	家 🖹 🛢 4:46 PM
DEX Connector release button Bluetooth connection button Bluetooth status LED	Charging status LEDs
1.Release the DEX pressing DEX Cor button.	Connector by nnector release
〈 Previous	Next >

- 4. On the DEX30, press the release button to open the DEX connector.
- 5. On the mobile computer, touch **Next**.



	🕈 💎 🖹 盲 11:50 AM
DEX Connector release button Bluetooth connection button Bluetooth status LED	Charging status LEDs
2.Press the Bluetoo button for 5 seco Bluetooth status	oth connection nds until the LED starts blinking.
〈 Previous	Next 📏

- 6. On the DX30, hold the Bluetooth connection button down for five seconds. The blue light flashes for a second, stops flashing, and then continues to flash indicating the DX30 is ready to pair.
- 7. On the mobile computer, touch **Next**.

The mobile computer beeps twice indicating that scanning is enabled.



* • Letter PM
3. Scan the MAC Address on the DX30.
Waiting for scan

- 8. Scan the MAC Address barcode on the DX30.
- 9. If scanning fails, the mobile computer beeps five times and pairing failed message appears.

Touch \triangleleft to return to previous screen.





10. The mobile computer begins pairing with the DX30.





11. After successfully pairing, the Pairing Successful message appears.



★ ♥ ► 4:50 PM
3. Scan the MAC Address on the DX30.
Pairing successful.
Exit

12. Touch Exit.



www.zebra.com