


Installation Instructions

This kit includes the parts and documentation necessary to install the Media Holder for Tear Kit into ZT610 600 dpi Micro Label printers.

Read these instructions thoroughly before attempting to install this kit.

Parts List

Before proceeding, verify that your kit contains the items for your printer listed. To reorder specific parts, go to zebra.com/parts, and select your printer model.



Item	Description	Qty
1	Media Holder	1

Prepare for Installation



NOTE: Retain all parts removed during disassembly, unless otherwise directed.




CAUTION: Turn off (O) the printer and disconnect it from the power source before performing the following procedure.


1. Open media door.
2. Load media into the printer.

Install Media Holder


1. Loosen the media holder screw so the holder moves freely on the media supply spindle.




2. Align the media holder with the media supply spindle.



-
3. Push the media holder in until it just touches the media.



4. Tighten the media holder screw to secure media holder in place.



Resume Printer Operation

1. Close the media door.
2. If you disconnected the AC power cord and interface cables, reconnect them, and then turn on (I) the printer.
3. If necessary, press **PAUSE** to resume printer operation.

The installation is complete.