

Installation Instruction for ST6084 Rubber Boot

I. Installation of the ST6084 Yellow Rubber Boot for Expansion Back WWAN End Cap

STEP 1.
INSERT HANDHELD THROUGH
OPENING IN THE RUBBER BOOT
AS SHOWN IN FIGURE A.



Figure A



Figure B

STEP 2.
SECURELY FIT THE FRONT
END OF THE HANDHELD IN
THE END OF RUBBER BOOT.
SEE FIGURE B.

Continued on other side... →

STEP 3.
 FIRMLY PULL BOTTOM CORNERS OF RUBBER BOOT (ONE AT A TIME WORKS BEST) AROUND THE END OF THE HANDHELD UNTIL SECURELY ENCLOSED. AS SHOWN IN FIGURES C AND D.



Figure C



Figure D



Figure E

STEP 4.
 FIGURE E SHOWS THE COMPLETED ASSEMBLY OF THE RUBBER BOOT.

Appendix A: Support Services

For technical support, please visit the Support section of our community Ingenuity Working: <http://community.pSION.com/support>.