Release Notes - MC67NA WM 6.5 - BSP v03.46.39 - HotFix CFE v01.04.00 Package

Introduction
Description
Package Details
Device Compatibility
Installation Requirements
Installation Instructions

Introduction

Release Date

HotFix CFE (Cumulative Fixes from Engineering) Package includes multiple SPR Hotfixes contained into a single package. The HotFix CFE Package helps the end users to keep up to date with all the SPR hotfixes for given product software release / revision

HotFix CFE packages are validated only by engineering validation team and the package follows Zebra Technologies HotFix Package Policy. Click here to view HotFix Package Policy. HotFix Support Policy

Description

The content and related Hot fixes that are included in this HotFix CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab / CFE_MC67_NA_034639_WM_EN_v010400_e_NB.cab is as follows.

SPR No	Synopsis
26945	Device unresponsive when customer application queries the WWAN status using RIL API and at the same time device fails to Critical Suspend
26947	Incorrect time stamp reported while receiving SMS message
26651	Numeric Key Repeat Issue: when SetAlpha API is called by application and at same time numeric keys are randomly pressed, sometimes a particular numeric key starts repeating.
26449	GPS position accuracy issue in stationary and moving positions

 $This\ HotFix\ CFE\ package\ CFE_MC67_NA_034639_WM_EN_v010400_e_WB\ /\ CFE_MC67_NA_034639_WM_EN_v010400_e_NB. cab\ obsoletes\ the\ following\ HotFix\ CFEs:$

HotFix CFE version	Product
CFE_MC67_NA_034639_WM_EN_v010300_e.cab	MC67NA
CFE_MC67_NA_034639_WM_EN_v010200_e.cab	MC67NA
CFE_MC67_NA_034639_WM_EN_v010102_e.cab	MC67NA

Note: Latest CFE package includes previous CFE package hot fixes and new SPR hotfix

Package Details

CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab (CFE package with Warm boot)

 $CFE_MC67_NA_034639_WM_EN_v010400_e_NB.cab~(CFE~package~without~Warm~boot)$

Device Compatibility

This HotFix CFE Package software release has been approved for use with the following Zebra devices.

Device	Operating System	BSP Version
MC67NA	WM 6.5	v03.46.39

Installation Requirements

The HotFix CFE cab can be deployed to the Mobile device through any one of the below mentioned methods. For installing the cab, the users should have at least one of the below mentioned tools

- Windows Mobile Device Center (For Windows Desktops)
- SD Cards / Micro SD cards
- MDM set up

Installation Instructions

For Normal installation of the PATCH:

- Windows Mobile Device Center (For Windows Desktops) Installation Instructions:
 - $1. \ \ Copy \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" \ file \ to \ the \ Application \ folder \ on \ the \ device. The property of the$
 - $2. \ \ Deploy the solution by tapping on the "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file.$
- SD Cards / Micro SD cards Installation Instructions:
 - $1. \ \ Copy \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" \ file \ to \ the \ SD \ card.$
 - $2. \ \ Deploy the solution by tapping on the "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab"$
 - $3. \ \ After successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm boot. The successful deployment of the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_WM_EN_v010400_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab" file, device will do an automatic warm between the \ "CFE_MC67_NA_034639_e_WB.cab "CFB_MC67_NA_034639_e_WB.cab "CFB_MC67_NA_034639_e_WB.cab "CFB_MC67_NA_034639_e_$

For MSP or REMOTE installation of the PATCH:

- $1. \ \ \, \text{Set up MDM (MSP, Soti, Airwatch, etc..)} \ \, \text{to send "CFE_MC67_NA_034639_WM_EN_v010400_e_NB.cab" file to the application folder of the devices the second of the devices of the devices$
- $2. \ \ \, \text{To deploy the solution, setup in MDM to install the cab file "CFE_MC67_NA_034639_WM_EN_v010400_e_NB.cab" file the cab file the ca$
- $3. \ \ Changes will take effect after a manual reboot of the terminal or if MDM reboots device.$

Release Date

June, 2015